





Image may include white goods, styling and other products, which may be available for you to purchase at an additional cost.

✕ = Coverside   ✕ = End panel   ○ = Metal bar   ⊙ = Spot   △ = Dishwasher front